




Government of **Western Australia**
Department of **Commerce**
Energy Safety

Your guide to Using gas safely in marine craft



A guide for safely using gas in a marine craft

Using gas safely in marine craft

When was the last time you checked your LP gas installation?

Follow this simple checklist to see if your marine craft is safe and complies with the regulations.



- The gas cylinder should be firmly secured and cylinder valves readily accessible for ease of operation.
- Cylinder compartments must:
 - Provide adequate protection against the weather.
 - Be constructed of material which is water and corrosion resistant.



Warning labels should be displayed next to the cylinder and appliance

- Be drained and vented to the outside atmosphere to prevent any accumulation of leaking gas within any enclosed area of the marine craft.
- Filling damaged or out-of-test-date cylinders is illegal and can be dangerous.
- Out of date cylinders must not be filled until tested and re-stamped by a certified gas cylinder test station.
- Ensure any installed gas refrigerator is sealed in a cupboard or enclosed compartment and is vented to the outside.

- ✓ Ensure the craft has adequate fixed ventilation.
- ✓ Regularly check the operation of all gas appliances and, if not functioning correctly, have them checked by an authorised gas fitter.
- ✓ Manual shut-off valves must be fitted to the inlet connection of each appliance and be accessible for operation.
- ✓ Use the cooking appliance or stove only for the purpose for which it was designed – cooking, eg not as a room heater.
- ✓ High pressure appliances must not be permanently installed in a marine craft, unless approved by a designated gas inspector.



Combustible gas detection systems

- ✓ Gas appliances must not be installed in a marine craft below the level of the main deck, unless an approved combustible gas detection system is installed.
- ✓ A typical gas detection installation consists of a control panel, solenoid valve and a minimum of two sensors.


Gas detection equipment





Safety tips

1. Close appliance operating knobs before opening cylinder valve.
2. Periodically check connections for leaks at the appliance, regulator and cylinder with soapy water.
3. Never use a match or flame when checking for leaks.
4. Close cylinder valve when appliances are not in use or when the gas cylinder is being filled.
5. Never leave an appliance with a continuous burning flame operating in any petrol driven vessel if unattended for a period of 12 hours or more.



6. Use the cooking appliance or stove only for the purpose for which it was designed – cooking, eg not as a room heater.

7. In the event of fire, immediately close cylinder valve.
8. Check the flammable gas detector, to determine if flammable vapours are present and the vessel cleared of any flammable vapour before lighting any LP gas appliance or starting the motor.
9. All spare gas cylinders, whether full or empty must be fitted with gas tight sealing plugs and all cylinder valves closed.
10. A licensed gas fitter must perform all additions or alterations to the LP gas system. (Consult your LP gas supplier.)
11. Appliances must not be altered without the authorisation of a gas inspector or the manufacturer and the work must be carried out by a licensed gas fitter.
12. Familiarise yourself with the odour of unburnt LP gas, to assist in the early detection of leaks.
13. All permanent ventilators, flues and vents should be checked regularly to ensure they are clear.
14. In the event of an accidental gas leak, close the cylinder valve and ventilate the vessel until the air is clear.

LP gas storage





Regulatory requirements

Any installation, servicing and repair work to the LP gas system can only legally be carried out by a gas fitter licensed by EnergySafety.

All licensed gas fitters are issued with a certificate of competency, permit or authorisation on the basis of their qualifications.

You can easily check if the gas fitter is licensed by requesting their licence number and contacting EnergySafety's Licensing Office for confirmation (details on back cover).

Unauthorised and do it yourself work is illegal and can result in prosecution.

Gasfitting is a job for the experts – always employ an authorised gas fitter.


The gas fitter who carries out any installation work must:

- Fix a compliance label to the vessel in a conspicuous position.

The Compliance Label is a statement from the gas fitter confirming compliance with regulatory requirements. It includes additional important information such as the gas fitter's details, Notice of Completion number and installation date.

- Provide you with a copy of the Notice of Completion specifying that the work complies with the Gas Standards (Gasfitting and Consumer Gas Installation) Regulations.

- Consider fitting fiddle rails and pot holders to cooking appliance to prevent unintentional movement of cooking utensils.



- Ensure any installed gas refrigerator, is sealed in a cupboard or other enclosed compartment and vented to the outside.
- Ensure that gas appliances are not installed or fitted in any marine craft exit or means of escape and must be located so that, in the event of a fire, the appliance will not impede anyone attempting to leave the craft.

Note: For commercial marine craft, the West Australian Department of Transport may have additional requirements which are detailed in the Uniform Shipping Laws Code.

For more information, contact Transport on (08) 9216 8237.

Advice is available by contacting the following gas suppliers:

Origin Energy Tel: 13 24 62

BOC Gases Tel: 13 12 62

EnergySafety Tel: (08) 6251 1900

Department of Commerce

EnergySafety Division

Level 1, 303 Sevenoaks Street (Cnr Grose Ave) Cannington
WA 6107

Telephone: (08) 6251 1900

Facsimile: (08) 6251 1901

National Relay Service: 13 36 77

Mailing address: Locked Bag 14 Cloisters Square WA 6850

Website: www.energysafety.wa.gov.au

Email: energysafety@commerce.wa.gov.au

Energy incident notification (24 hours): 1800 678 198

Regional offices

Goldfields/Esperance	(08) 9026 3250
Great Southern	(08) 9842 8366
Kimberley	(08) 9169 2811
Mid-West	(08) 9964 5644
North-West	(08) 9185 0900
South-West	(08) 9722 2888

If you require the services of an interpreter, contact the Translating and Interpreting Services (TIS) on 131 450 and ask for connection to EnergySafety on 9422 5200.

This publication is available on request in other formats to assist people with special needs.

ESWA G017 1109